


SENTINEL 4 LINE ISOLATION



The Sentinel 4 line isolation controller can be interconnected to any A. S.T Sentinel 4 door entry system, anywhere on the system. On detection of a fault the controller will immediately isolate that particular circuit from the system and automatically reconnect when the fault has been rectified. Being self monitoring and having self resetting fuses, the S4LI is a maintenance free unit.

- ◆ **CAN BE LOCATED ANYWHERE ON SYSTEM.**
- ◆ **CAN BE POPULATED FROM 4 TO 8 OUTPUTS.**
- ◆ **IDC TYPE PHONE CONNECTION PORTS.**
- ◆ **NO LIMITATION TO NUMBER USED ON ANY SYSTEM.**